



**ASSEMBLY NOTES:**  
 NOTE 1: R25 SHOULD BE ASSEMBLED SO ITS LEGS ARE STILL ACCESSIBLE AFTER POPULATION.  
 NOTE 2: U10 SHOULD NOT BE SOLDERED DIRECTLY TO THE PCB, A SOCKET SHOULD BE USED.  
 NOTE 3: C44, C45 & C46 ARE TO BE PLACED AS CLOSE TO J13 AS POSSIBLE.

THIS IS A MIXED SIGNAL CIRCUIT